

INSTRUCTION SHEET

for 279127 Caster Kit

When using this replacement kit for No. 345841 caster, it will be necessary for you to place two (2) of the washers between the caster and the cabinet on those casters not being changed. The replacement caster is larger in diameter than the one being replaced. Washers are needed to level the machine. When using this replacement kit for No. 349999 caster, the washers are not needed and can be discarded.

FEUILLE D'INSTRUCTIONS

Nécessaire de roulettes 279127

Lorsque l'on utilise ce nécessaire pour remplacer les roulettes 345841, il faudra mettre deux (2) rondelles entre les roulettes qui ne sont pas remplacées et la carrosserie. Le diamètre de la roulette de rechange est plus grand que celle remplacée. Les rondelles servent à mettre la machine de niveau. Lorsque l'on utilise ce nécessaire de rechange pour la roulette n° 349999, les rondelles ne seront pas utilisées et elles pourront être jetées.