

ASSEMBLY INSTRUCTION

ITEM# : 502-BR31

DESCRIPTION: 9 DRAWER DRESSER


Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all parts and compare with the parts list below.

PARTS LIST

NO.	SKETCH	DESCRIPTION	QTY
A		Dresser	1
B		Bun foot	4
C		Center Leg	1

HARDWARE LIST


NO	DRAWING	DESCRIPTION	QTY
1		Bolt Ø5/16"*100mm	4
2		Spring Washer Ø5/16"*12mm	4
3		Flat Washer Ø5/16"x19mm	4
4		Allen Key 4mm	1
5		Wood Dowel Ø8*30mm	4
6		Tipping Restraint Kit	1Set



Complete Assembly



Push tab down
to remove drawer



HOW TO OPEN DRAWER


To remove drawer, simultaneously pull tab up on one side and put down on the other and remove drawer.



Push tab up
to remove drawer


CLEANING INSTRUCTION

Clean the item surface with a furniture polish and a soft cloth.




Note:
Remove bun foot inside

Step 1



1 OF 1

Step 2



MADE IN VIETNAM