

CF720M0W PART LIST

No	Part Name	Part No	pcs
1	foamed door assy	312090505518	1
2	door gasket	312240100466	1
3	self-tapping screw	312310200014	5
4	compressor room cover	312039900811	1
5	dry filter	312200600036	1
6	compressor supporting board	312031000117	1
7	screw	312310400015	4
8	Electrical connection line	312151400079	1
9	compressor	312200400679	1
10	vibration pad		4
11	compressor bolts		4
12	thermostat	312180100107	1
13	Electrical box	312121100304	1
14	Indication lamp	312180300117	1
15	Thermostat knob	312121200114	1
16	cap drain	312120500142	1
17	ajustable bottom feet part	312121900032	2
18	foamed box assy	312090103591	1
19	Drain cork assy	312120500145	1
20	basket	312280200181	1
21	hinge assy	312031100238	2
22	upper cover hinge	312122300155	2
23	lower cover hinge	312122300156	2
24	screw	312310200035	14
25	compressor room fan heat shield	312120400063	1
26	screw	312310200083	1
27	Power supply cord with plug	312151100261	1

