

SAR1701N1B, SAR1702N3S Exploded View



Item	Spare parts Name	Quantity(PCS)
1	Door	1

2	Door Gasket	1
3	Short door fixing bar	1
4	Long door fixing bar	1
5	Small shelf	1
6	Big shelf	1
7	Knob	1
8	Control box cover	1
9	PCB	1
10	Control box base	1
11	Plastic cover	1
12	Cabinet	1
13	Upper hinge	1
14	Screws	3
15	Upper hinge cover	1
16	Heat sink fan	2
17	Water break	1
18	Cooling sheet	1
19	Cooling module	1
20	EVA washer	1
21	Heat pipe	1
22	Back cover	1
23	Power cord storage box	1
24	Water drip tray	1
25	Power cord	1
26	Power cord accessories	1
27	PCB	1
28	High robber leg	2
29	Bottom hinge	1
30	Low robber leg	1
31	Adjustable leg	1
32	Aluminum cooling block	1
33	Cold sink fan	1
34	Cold sink fan cover	1

FOR DCSR17N3S-IS ONLY

Item	Spare parts Name	Quantity(PCS)
35	ACDC cover(Exterior)	1
36	ACDC sliding cover	1
37	ACDC cover(Interior)	1
38	AC socket	1
39	DC socket	1
40	AC power cable(Detachable)	1
27=41	PCB	1
42	DC power cable(Detachable)	1