


# Microwave Combination Oven

**E30MC75JSS** designer series



## Wave-Touch® Controls

Sleek control panel illuminates with just a touch – giving you more control over your cooking – and fades away to an uncluttered display after an option is selected.



## Smooth-Glide® Oven Racks

Ball bearing oven racks glide with unparalleled ease and extend fully for effortless access.



## CustomConvect3™ Convection Technology

Distributes heat evenly throughout the oven by adding a third cooking element plus a variable speed fan.



## Custom-Set™ Options with Temperature Probe

Seven cooking modes with eight cooking functions give you more cooking flexibility and control – and the temperature probe monitors the progress of your meat dishes.

## 30" BUILT-IN MICROWAVE COMBINATION OVEN

### MICROWAVE FEATURES

|                            |             |
|----------------------------|-------------|
| Oven Cavity                | 1.5 Cu. Ft. |
| Watts                      | 900         |
| Stainless Steel Interior   | Yes         |
| Interior Krypton Light     | Yes         |
| Porcelain Enamel Turntable | Yes         |

### MICROWAVE CONTROL OPTIONS

|                                                                                                  |     |
|--------------------------------------------------------------------------------------------------|-----|
| Wave-Touch® Electronic Controls                                                                  | Yes |
| Cook-2-Perfection® Technology                                                                    | Yes |
| Electronic Clock & Timer                                                                         | Yes |
| Humidity Sensor                                                                                  | Yes |
| Power Levels                                                                                     | 11  |
| Touch Pad Controls                                                                               | 37  |
| Auto Start                                                                                       | Yes |
| Auto Defrost Options                                                                             | 6   |
| Automatic Cooking Options –                                                                      |     |
| Pizza Slice (1), Snacks (3), Kid's Meals (3)                                                     |     |
| Softening/Melt (4), Beverage (1)                                                                 | 12  |
| Convection Cook Categories –                                                                     |     |
| Auto Broil (4), Auto Roast (4), Auto Bake (4)                                                    | 12  |
| Auto Reheat Categories –                                                                         |     |
| Breads/Muffins (2), Pasta (1)                                                                    | 3   |
| Auto Sensor Cooking –                                                                            |     |
| Cook (5), Reheat (1), Popcorn (2), Baked Potato (1), Frozen Vegetables (1), Fresh Vegetables (2) | 12  |
| Stage Cooking Options                                                                            | 4   |
| Add 30 Seconds                                                                                   | Yes |
| Electronic Lockout                                                                               | Yes |
| Adjustable Sound Level for Timers/Reminders                                                      | Yes |
| More/Less Function                                                                               | Yes |
| Power Failure Indicator                                                                          | Yes |

### OVEN FEATURES

|                                                         |             |
|---------------------------------------------------------|-------------|
| Oven Cavity                                             | 4.2 Cu. Ft. |
| Cobalt Blue Interior                                    | Yes         |
| Smooth-Glide® Racks/Standard Racks                      | 3/1         |
| CustomConvect3™ Convection System                       | Yes         |
| Dual-Halogen Theatre Lighting                           | Yes         |
| Removable Cool-Touch™ Oven Door with Extra-Large Window | Yes         |
| "My Favorite" Settings                                  | Yes         |
| Convection Conversion                                   | Yes         |
| Custom-Set™ Options with Temperature Probe              | Yes         |
| Light Clean/Heavy Clean                                 | Yes         |
| Self-Cleaning with Auto-Safety Latch™                   | Yes         |
| Self-Cleaning Cycle with Rack Removal Alert             | Yes         |
| Dual Radiant™ Baking System                             | Yes         |
| Eight-Pass Broil & Radiant Bake Element                 | Yes         |
| Sabbath Mode (Star-K® Certified)                        | Yes         |

### OVEN CONTROLS

|                                            |     |
|--------------------------------------------|-----|
| Wave-Touch™ Electronic Controls            | Yes |
| Electronic Clock/Timer/Temperature Display | Yes |
| Automatic Oven – Delay, Cook & Off         | Yes |
| Electronic Lockout                         | Yes |
| Automatic Oven Shutoff – 12 Hour           | Yes |
| Integrated Halogen Oven Light – Touch Pad  | Yes |

### SPECIFICATIONS

|                                             |                              |
|---------------------------------------------|------------------------------|
| Microwave Oven Interior (HxWxD)             | 9-5/8" x 16-1/8" x 16-1/8"   |
| Oven Interior (HxWxD)                       | 16-1/2" x 24-1/8" x 18-1/32" |
| Product Dimensions –                        |                              |
| Height                                      | 46-5/8"                      |
| Width                                       | 30"                          |
| Depth (Including Door)                      | 24-5/8"                      |
| Power Supply Connection Location            | Left Bottom Rear             |
| Connected Load (kW Rating) @ 240/208 Volts1 | 7.1/6.1                      |
| Amps @ 240/208 Volts                        | 30/30                        |
| Minimum Circuit Required (Amps)             | 40                           |
| Shipping Weight (Approx.)                   | 250                          |


NOTE: Always consult local and national electric codes. Refer to Product Installation Guide for detailed installation instructions on the web at [electroluxicon.com](http://electroluxicon.com).

Specifications subject to change.

# Microwave Combination Oven

E30MC75JSS designer series

Electrolux | ICON®



## 30" Built-In Microwave Combination Oven Specifications

- Product Weight – 240 Lbs.
- Single phase 3- or 4-wire cable, 120/240 or 120/208 Volt, 60 Hertz AC only electrical supply with ground required on separate circuit fused on both sides of line.
- Connected Load (kW Rating) @ 240/208 Volts = 7.1/6.1 kW
- Amps @ 240/208 Volts = 30/30 Amps
- Recommended Circuit Breaker – 40 Amps
- Always consult local and national electric codes.
- Minimum 23-1/4" clearance for oven door depth when open.
- Suggested distance from floor is 11-1/2". Minimum required distance is 4-1/2".

- Minimum 24" deep cutout dimension is critical for proper installation, to ensure that oven's faceplate will fit flush against cabinet front.
- Full oven base of solid plywood or similar material required, capable of supporting 300 Lbs.
- Base must be level and cabinet front must be square.
- Microwave Combination Oven is NOT approved to be used in stackable or side-by-side installation.

**Note:** For planning purposes only. Refer to Product Installation Guide on the web at [electroluxicon.com](http://electroluxicon.com) for detailed instructions.

## Electrolux Major Appliances, N.A.

USA • 10200 David Taylor Drive • Charlotte, NC 28262 • 1-877-4electrolux (1-877-435-3287) • [electroluxicon.com](http://electroluxicon.com)  
 CANADA • 5855 Terry Fox Way • Mississauga, ON L5V 3E4 • 1-800-265-8352 • [electroluxicon.ca](http://electroluxicon.ca)

E30MC75JSS 04/11

© 2011 Electrolux Home Products, Inc.



High standards of quality at Electrolux Home Products, Inc. mean we are constantly working to improve our products. We reserve the right to change specifications or discontinue models without notice.

Printed in the U.S.A.

# General Installation Guidelines


For Installation with Counter-Depth Side-by-Side Refrigerator



Electrolux | I C O N<sup>®</sup>

Use these dimensions and clearance instructions for planning purposes only. For detailed installation instructions, refer to installation guide, packed with product, or on the web at [electroluxicon.com](http://electroluxicon.com).


Front



When installing built-in cooking appliances in combination, 2"-high minimum visible gap between appliance faceplates required.

Clearance information for cooking appliances, provided in specific product's installation guide.


Top



\*When installing side-by-side refrigerator adjacent to wall, cabinet or another appliance that extends beyond front edge of unit, 20" minimum clearance recommended to allow for optimum 120° to 180° door swing, providing complete drawer / crisper access and removal. (Absolute 4-1/2" minimum clearance will ONLY allow for 90° door swing which will provide limited drawer/crisper access with restricted removal.)


When installing appliance with sliding drawer or drop-down door directly across from obstructions, provide sufficient clearance for drawer extension or door swing.

Front



To ensure optimum performance, avoid installing refrigeration appliances in direct sunlight or near heat source.

Top



When installing appliance with side-swing door adjacent to wall, cabinet, or other obstruction that extends beyond front edge of appliance, door swing and handle clearance must be sufficient to allow access to appliance interior.

When installing appliance with sliding drawer or drop-down door directly across from obstructions, provide sufficient clearance for drawer extension or door swing.

When installing appliance with sliding drawer or drop-down door adjacent to wall, cabinet, or other obstruction that extends beyond front edge of appliance, allow 2" minimum clearance between drawer or door and obstruction.

## Electrolux Major Appliances, N.A.

USA • 10200 David Taylor Drive • Charlotte, NC 28262 • 1-877-4electrolux (1-877-435-3287) • [electroluxicon.com](http://electroluxicon.com)  
CANADA • 5855 Terry Fox Way • Mississauga, ON L5V 3E4 • 1-800-265-8352 • [electroluxicon.ca](http://electroluxicon.ca)

INSTGDLNS\_SSR EI 02/12

© 2012 Electrolux Home Products, Inc.

High standards of quality at Electrolux Home Products, Inc. mean we are constantly working to improve our products. We reserve the right to change specifications or discontinue models without notice.

# General Installation Guidelines


For Installation with Counter-Depth French Door Refrigerator



Electrolux | I C O N<sup>®</sup>

Use these dimensions and clearance instructions for planning purposes only. For detailed installation instructions, refer to installation guide, packed with product, or on the web at [electroluxicon.com](http://electroluxicon.com).

Front




When installing built-in cooking appliances in combination, 2"-high minimum visible gap between appliance faceplates required.

Clearance information for cooking appliances, provided in specific product's installation guide.

When installing ventilation unit above cooking product, provide 30" to 36" clearance between cooking surface and bottom of ventilator.


Top



\*When installing French door refrigerator adjacent to wall, cabinet or another appliance that extends beyond front edge of unit, 20" minimum clearance recommended to allow for optimum 120° to 180° door swing, providing complete drawer / crisper access and removal. (Absolute 4-1/2" minimum clearance will ONLY allow for 90° door swing which will provide limited drawer / crisper access with restricted removal.)


When installing appliance with sliding drawer or drop-down door directly across from obstructions, provide sufficient clearance for drawer extension or door swing.

Front



To ensure optimum performance, avoid installing refrigeration appliances in direct sunlight or near heat source.

Top



When installing appliance with side-swing door adjacent to wall, cabinet, or other obstruction that extends beyond front edge of appliance, door swing and handle clearance must be sufficient to allow access to appliance interior.

When installing appliance with sliding drawer or drop-down door directly across from obstructions, provide sufficient clearance for drawer extension or door swing.

When installing appliance with sliding drawer or drop-down door adjacent to wall, cabinet, or other obstruction that extends beyond front edge of appliance, allow 2" minimum clearance between drawer or door and obstruction.

## Electrolux Major Appliances, N.A.

USA • 10200 David Taylor Drive • Charlotte, NC 28262 • 1-877-4electrolux (1-877-435-3287) • [electroluxicon.com](http://electroluxicon.com)  
CANADA • 5855 Terry Fox Way • Mississauga, ON L5V 3E4 • 1-800-265-8352 • [electroluxicon.ca](http://electroluxicon.ca)

INSTGDLNS\_FDR EI 02/12

© 2012 Electrolux Home Products, Inc.

High standards of quality at Electrolux Home Products, Inc. mean we are constantly working to improve our products. We reserve the right to change specifications or discontinue models without notice.



# General Installation Guidelines


For Installation with All Refrigerator or All Freezer



Electrolux | I C O N<sup>®</sup>

Use these dimensions and clearance instructions for planning purposes only. For detailed installation instructions, refer to installation guide, packed with product, or on the web at [electroluxicon.com](http://electroluxicon.com).


Front



When installing built-in cooking appliances in combination, 2"-high minimum visible gap between appliance faceplates required.


Clearance information for cooking appliances, provided in specific product's installation guide.

Top




Front

To ensure optimum performance, avoid installing refrigeration appliances in direct sunlight or near heat source.



Top

When installing appliance with side-swing door adjacent to wall, cabinet, or other obstruction that extends beyond front edge of appliance, door swing and handle clearance must be sufficient to allow access to appliance interior.



## Electrolux Major Appliances, N.A.

USA • 10200 David Taylor Drive • Charlotte, NC 28262 • 1-877-4electrolux (1-877-435-3287) • [electroluxicon.com](http://electroluxicon.com)  
CANADA • 5855 Terry Fox Way • Mississauga, ON L5V 3E4 • 1-800-265-8352 • [electroluxicon.ca](http://electroluxicon.ca)

INSTGDLNS\_ARAF EI 02/12

© 2012 Electrolux Home Products, Inc.

High standards of quality at Electrolux Home Products, Inc. mean we are constantly working to improve our products. We reserve the right to change specifications or discontinue models without notice.