

SETTING FREQUENCY OF CLEANINGS

THE DISPENSING PUMP BOARD CONTAINS THE FOLLOWING:

1. SET SELECTOR SWITCH FOR THE FREQUENCY OF CLEAN CYCLE DESIRED. THE FOUR POSITIONS ARE AS FOLLOWING:

<u>SWITCH POSITION</u>	<u>TIME BETWEEN CLEANINGS</u>
0	NO CLEANINGS (UNIT OFF)
1	APPROXIMATELY 2 WEEKS (1120 HARVESTS)
2	APPROXIMATELY 4 WEEKS (2240 HARVESTS)
3	APPROXIMATELY 12 WEEKS (6720 HARVESTS)

