

Wiring Diagram

IF0300 / IT0420 / IT0450 / IT0500 / IT0620 / IT0750

AIR-COOLED & WATER-COOLED SELF-CONTAINED - 1 PHASE

(Includes Marine Disconnect Switch)

