


WASTE KING

Illustrated Parts for L-3300



Drain Elbow Kit - 1026

Rubber Gasket

Screws

Drain Elbow

Other Available Accessories



Air Switch Remote Controller

- Installs into existing sink hole to operate disposer with plunger air switch.
- Perfect application for island countertops or where electric switch is unavailable.
- No wiring connections or code restrictions.

Air Switch Base Unit

Air Switch Remote Controller	ARC-4200
Additional Air Switch Button Finish Options:	
Chrome	AS-4201-CH
Satin Nickel	AS-4201-SN
Polished Brass	AS-4201-BR
White	AS-4201-WH
Almond	AS-4201-AL
Biscuit	AS-4201-BIS

Dishwasher Connector Kit -
(connects 1-1/4", 1" and 3/4" outside diameter
dishwasher drain hoses to the dishwasher inlet)

1023



Unjamming Wrench

1037



Disposal purchase comes with all Included Parts,
Other Available Accessories can be purchased separately

FOR MORE INFORMATION CALL: 1-800-854-3229
WasteKing.com