


# USER GUIDE

## Parts



| UOKR124-SS01A |                             |             |
|---------------|-----------------------------|-------------|
| 1             | ANTI-TIP BRACKET            | 80-54244-00 |
| 2             | BACK PANEL                  | 80-54204-00 |
| 3             | CAP ASSEMBLY W/GASKET       | 80-54940-00 |
| 4             | COMPRESSOR ELECTRICALS ONLY | 80-54149-00 |
| 5             | COMPRESSOR W/ELECTRICALS    | 80-54150-00 |
| 6             | CONDENSER ASSEMBLY          | 80-54212-00 |
| 7             | CONDENSER FAN W/SCREWS      | 80-54014-00 |
| 8             | DISPLAY/MAIN BOARD ASSEMBLY | 80-55533-00 |
| 9             | DOOR ASSEMBLY               | 80-55421-00 |
| 10            | DRAIN PAN                   | 80-54217-00 |
| 11            | DRIER                       | 80-54055-00 |
| 12            | ENCLOSURE ASSEMBLY          | 80-54532-00 |
| 13            | EVAPORATOR ASSEMBLY         | 80-55411-00 |
| 14            | EVAPORATOR COVER            | 80-55513-00 |
| 15            | EVAPORATOR FAN              | 80-54321-00 |
| 16            | EVAPORATOR FAN COVER        | 80-54320-00 |
| 17            | GASKET, DOOR                | 80-55498-00 |
| 18            | GRILLE ASSEMBLY             | 80-55412-00 |
| 19            | HINGE ASSEMBLY              | 80-55418-00 |
| 20            | HINGE COVER                 | 80-55499-00 |
| 21            | LED LIGHT STRIP AND COVER   | 80-54000-00 |
| 22            | LEG LEVELERS (4)            | 80-54019-00 |
| 23            | POWER CORD*                 | 80-55401-00 |
| 24            | REED SWITCH ASSEMBLY        | 80-54284-00 |
| 25            | THERMISTOR                  | 80-54006-00 |
| 26            | THERMISTOR COVER            | 80-54237-00 |
| 27            | WIRE HARNESS*               | 80-55402-00 |
| 28            | WIRE SHELF (1)              | 80-54329-00 |

\*NOT SHOWN