


646220, 646221

EN Aqua secure hoses

The aqua secure hose consists of a sealed inner and outer hose and a leak detection / shut-off assembly. A spring holds a plunger open allowing the inner hose to carry water. If an inner hose ever should leak, water fills the outer hose where a sponge in the hose end (connected to the water line) absorbs water, pulling a plunger down to stop water flow and show **red** in the indicator window. The outer hose is sealed and won't leak.



Any remaining water pressure won't re-open the hose, but will help keep the hose closed.

The hose has a one-time failure duty. If an inner hose should ever leak where the indicator shows **red**, the hose must be replaced.

Aqua secure hoses stop hose leaks, whether appliances are on or not. They're superior to braided hoses, whether nylon or ss, and can be used with any washer (or misting dryer) with standard US threads (3/4" NH, 11.5 threads/inch).

Aqua secure hoses protect homes and provide peace of mind for people on vacation and those asleep, busy or who don't shut off water valves when washers (and misting dryers) aren't in use.